Menon Acoustics

Contents

Get to Know Your ROCSTA™ OVI 4
How to Best Experience Your ROCSTA™ OVI 8
Troubleshooting 10
Safety Disclaimer 12
Limited Warranty Information 13
Safety Information 14
Compliance 15
Register Your ROCTSA™ 16
Connect with Us 17

Stay Up To Date With Us

www.	For latest additional information on troubleshooting, safety disclaimer, limited warranty information and FAQ's, please visit **WWW.MENON-ACOUSTICS.COM**

Get to Know Your ROCSTA™ OVI



1. Charging Indicator ❶

I. The red-colored LED light indicates that the charging process is ongoing.

II. The green-colored LED light indicates that the charging process is complete.

2. DC 5V Charge Port. ❷

3. Buckle for Hand Strap.



1. Power On/Off Button
2. Reduce Volume Button
3. Increase Volume Button

Step 1 : Pair Your ROCSTA™



1. Turn on the Bluetooth feature on your device.
2. The Bluetooth logo should appear on your device screen now.
3. Hold Button ❶ for 8 seconds to switch on the speakers. The blue-colored LED light will start blinking. At this juncture, your device is ready to be paired with ROCSTA speakers.
4. From your device, under the Bluetooth menu, select 'Search'. Wait for 2 seconds to 5 seconds and you should be able to see the name 'ROCSTA OVI'
5. Select 'ROCSTA OVI' and your device will be automatically paired to the ROCSTA speakers.
6. If prompted for a password, please enter "0000" on your device.
7. Once the connection is established, you will hear a beep, acknowledging that your device has been paired to ROCSTA.

Step 2 : Play Your ROCSTA™



1. Button ❶
I. Hold this button for 5 seconds to turn on/off the speakers (the beep acts as an indicator).
II. Click on this button to pause/play the music.

2. Button ❷
I. Hold this button to reduce the volume.
II. Click on this button to return to the beginning of the song.
III. Double-click on this button to return to previous song.

3. Button ❸
I. Hold this button to increase the volume.
II. Click on this button once to move to the next song.
III. A beep will be heard when the volume reaches maximum level (volume control can also be set on the paired device).

WHY IS IT IMPORTANT ?

The MP3 compression format creates files that don't sound exactly like the original recording -- it's a lossy format. MP3 encoders have to lose audio information. Lossless compression formats don't sacrifice any audio information.

The Outcome of High Bit Rate Tracks ?

It will demonstrate the deep, rich musical performance this speaker is designed to deliver.

WHICH IS RIGHT FOR YOU?

	MP3 Generic	AAC Apple iPod	WMA Microsoft
192 kbps	good quality / small size	better quality / small size	better quality / small size
256 kbps	better quality / medium size	best quality / medium size	best quality / medium size
320 kbps	best quality / large size	best quality / large size	best quality / large size

FLAC & AIFF

FLAC & AIFF are lossless archival formats that consume huge disk space and don't play on portable devices. Because they are lossless (Preserves the original fidelity). You can "future proof" your collection in digital form by adding FLAC or AIFF to your order. Encode them to any format!

Troubleshooting

1. Most Bluetooth devices will connect with this ROCSTA™ speaker automatically after they've been paired once. However, for selected devices from certain manufacturers, this feature does not apply due to different Bluetooth technologies being used. In such an instance, the device needs to be paired again with ROCSTA™.
2. If Bluetooth connection problems still persist after initial pairing has been made, the following procedure can be implemented to resolve the possible issue;-
    I. Delete the paired name as 'ROCKSTA V.1' in the pairing list of the device.
    II. Re-pair the device to the speaker using the instructions given above.

* Note:
I. Please ensure that the device is placed within 1 meter of the speakers during pairing.
II. Please ensure that both your device and the speaker are not connected to any other device.
III. Only one device should be connected to the speaker at any given time.

3. What to do if the device is still unable to play music despite its successful pairing with the speaker?
   I. For some Bluetooth devices, such as PC (Windows and Mac OS), you may need to manual select ROCSTA V.1 as your preferred 'Audio Device'.
   II. In other instances, you may have to perform checks to see if your equipment can sup port the A2DP function (for additional details, we recommend that you refer to the device manufacturer's manual).
4. Certain devices may experience delay and lag during music playback. This delay is a result of the Bluetooth wireless technology being used by the particular device.
5. The following factors may also cause disconnection between your device and the speaker;
   I. Low power for the speaker;
   II. Low power for your device; and
   III. Interference from an alternate paired device
6. If the speakers do not switch on or off, we suggest that you disconnect the Bluetooth connection for about 5 minutes and power-off the speakers. Post 5 minutes you can restart the speaker.

Safety Disclaimer

1. The short-wave radio signal emitted from your ROCSTA™ Bluetooth Speakers cannot be used in locations where it is forbidden or not permitted, such as on airplanes, medical institutions, and gas stations among others.
2. Do not use your ROCSTA™ Bluetooth Speakers within a 20 centimeter radius of an electronic pacemaker, as the emitted radio waves may significantly affect the performance of the equipment.
3. Compatibility statement: Wireless performance of this ROCSTA™ speaker depends on the Bluetooth technology being used on your pairing device. Some devices use inferior Bluetooth chipsets and modules that significantly affect the quality, performance, and range of the intended pairing device. Menon Acoustics is not responsible for data loss, performance, and quality issues caused by ROCSTA™ or the paired device.

Limited Warranty Information

This Menon Acoustics product carries a guarantee against defects in workmanship and materials .The terms of the guarantee apply to the country of purchase but will be met by authorized Menon Acoustics dealers in other countries.
The guarantee period applying to the country of purchase takes priority over guarantee periods applying in other countries, even where differences exist. In order to obtain service under this guarantee, a receipt stating the following information is required :

- Name of product and type number
- Model Number
- Date of Purchase
- Guarantee Period
- Dealer's or supplier's signature

Important info : Please keep your packaging. In the event that the drive should need to be repaired or serviced, it must be returned in its original packaging.

Safety Information

Please read this owner's guide

Please take the time to follow the instructions in this owner's guide carefully.
It will help you to properly use your new Menon Acoustics product and enjoy its features.
Please save this owner's guide for future reference.


CAUTION
RISK OF ELECTRICAL SHOCK
DO NOT OPEN
CAUTION : TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED PERSONNEL.

Compliance

This product conforms to all EU Directive requirements as applicable by law.
The complete Declaration of Conformity can be found at our website.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
i. This device may not cause harmful interference, and
ii. This device must accept any interference received, including interference that may cause undesired operation.

This product is subject to European Union regulations that promote the re-use and recycling of used electrical and equipment. This product required the extraction and use of natural resources and may contain hazardous substances .The symbol indicates that this product must not be disposed of with your other household waste.

Register Your ROCSTA™

Registering your product ensures you'll receive any applicable software or product updates for years of continued enjoyment.

Please register your product by visiting **WWW.MENON-ACOUSTICS.COM/REGISTER** or scanning the QR code. Failure to complete this form does not diminish your limited warranty rights.

Scan this QR Code with your mobile device.

Don't have the app?
Search for "QR Code Reader" in your app store.

Connect With Us

www.menon-acoustics.com

www.menon-acoustics.com/support

support@menon-acoustics.com

facebook.com/menonacoustics